

For Maintenance Purposes Only

AUTOMATED TELLER MACHINE/ CASH DISPENSER

BILL DISPENSER

OPERATOR'S GUIDE

FUJITSU FRONTECH

Foreword

Before operating F56/53, please read this guide carefully to enable proper use.
Keep this guide in a safe and handy place for easy reference whenever necessary.

CONTENTS


CHAPTER 1 OUTLINE-----	1-1
1.1 Pool Type (Front Access)-----	1-1
1.2 Pool Type (Rear Access)-----	1-1
1.3 Tray Type -----	1-2
1.4 Spray Type-----	1-2
CHAPTER 2 CASH CASSETTE-----	2-1
2.1 Cash Cassette -----	2-1
2.1.1 Parts -----	2-1
2.1.2 Inserting and removing a cash cassette-----	2-3
2.1.3 Loading bill -----	2-6
2.1.4 Setting the bill type-----	2-10
2.1.5 How to handle a cassette -----	2-12
2.1.6 Notes on loading bills-----	2-13

CHAPTER 1 OUTLINE


The figure below shows F56 bill dispenser.

There are two types of Top units available.

1.1 Pool Type(Front Access)




1.2 Pool Type(Rear Access)



The figure below shows F53 bill dispenser.
There are two types of Top units available.

1.3 Tray type



1.4 Spray type





CHAPTER 2 CASH CASSETTE

2.1 Cash Cassette

F56/F53 can support up to 6 cassettes and each of them consists of the parts listed in Section 2.1.1.

2.1.1 Parts



Lid:	Top cover of the cash cassette
Handle:	Used for carrying the cash cassette
Chassis:	Main frame of the cash cassette
Denomination magnet:	Used to specify bill denomination for each cassette
Magnet slot label:	Identifies each of magnet slots where denomination magnets are inserted
Pressure plate:	Used to hold a bill bunch loaded into the cash cassette
Side guide:	Used to align the long edges of the bills in the cash cassette
Rear guide:	Used to align the short edges of the bills in the cash cassette




2.1.2 Inserting and removing a cash cassette from the dispenser

-Removing a cassette

- (1) Press and hold the push-button at the bottom right corner of a cassette and remove the cassette from the dispenser.






Caution

Be careful not to pinch your fingers between the dispenser and cassette.

-Inserting a cassette

(1) Insert a cassette into the dispenser and push it forward as far as it goes.



Notes

- 1.All cash cassettes used in the F56/F53 are compatible with each other.
- 2.The F56/F53 cannot start operation when no cassette is installed.

Caution

Be careful not to pinch your fingers between the dispenser and cassette.


2.1.3 Loading bills

(1) Push and hold the green button on the front side of a cassette to release the lock and open the lid.




Button

(2) Lift the lid up in the direction of arrow b to completely open the cassette.




(3) Pull the pressure plate toward you and raise it along the grooves on both sides. When the pressure plate reaches the top of the groove, push the pressure plate forward so that it can be settled in the slots leading out of the grooves.




(4) Before loading bills into the cassette, jog and align them.



(5) Load the bills into the cassette so that they fit between the side guides.



(6) Lower down the pressure plate to hold the loaded bills.



(7) Close the lid .

(8) Insert the cassette into the dispenser and push it all as far as it goes.


Notes

1. Do not load more than 500 bills into one cassette.
(Reference value, New bills which thickness is 0.12mm)
2. Do not cram the bill.

2.1.4 Setting bill denomination for a cash cassette

Look at “Denomination magnet combination table” on page 2-11 and find a combination of denomination magnets that corresponds to a denomination you wish to set. There are four magnet slots available and two of them are always used to specify one denomination for a cash cassette.

- (1) Insert two denomination magnets into two slots respectively with their white top face facing upward and their white side face inserted first.



*Make sure that denomination magnets are completely fitted into slots under a claw.



The following shows labels attached below each slot which denomination magnets are inserted into.



	a	b	c	d
A				
B				
C				
D				
E				
F				

Denomination magnet combination table

With its 4 magnet slots,each cassette can support 6 different magnet combinations,that is,6 different denominations.

2.1.5 How to handle a cassette

Make sure to hold the handle on top of a cash cassette when carrying.



Good example




Bad example

×

2.1.6 Notes on loading bills


Before loading bills, follow the instructions below for proper operation.

- (1) Fan the stack of bills before loading.




- (2) Align bills before loading them.


Don't allow any bill protruding from the bunch.




- (3) Load bills in staggered units of 100 sheets so that the stack of bills does not bulge.




(4) Straighten any folded corners of bills as much as possible before loading.




(5) Do not use bills repaired with tape.



(6) When loading a bill bunch into a cassette, make sure that the bottommost bill gets no twist or fold.




(7) Please smooth the bended or crushed bills out.




(8) Do not use the bills having serious wrinkles or broken section wherein paper fiber is broken and separation begin.

Broken section




(9) Do not use the bills having adequate life or sizing, but stained seriously.




(10) Do not use the bills having serious worn out place.

The bill thickness should not be less than 0.08mm

(11) Do not use the bills with holes. (Perforated bills)




(12) Do not use the bills ragged and cannot be held straightly when one end is supported by a hand.




(13)



Bill distortion should not exceed 5 mm.




Do not use.




Bill distortion should not exceed 5 mm



Bill distortion should not exceed 5 mm.





Do not use.




(14) Do not use the bills with curl.


Bill distortion should not exceed 5 mm.




Bill distortion should not exceed 5 mm.





(15) Do not the bills with stapling needle.





(16) Do not use the bills greatly curved. (bills tied by band seal, etc.)





(17) Do not use the bills with end folding.



(18) Do not the bills folded at middle portion.




(19) Do not use the waving bills.



(20) Caution for new bills

Once arrange the bills as shown below, and then introduce them into the cash cassette.

Paste is used for new bills packing.



Without removing paste, bills pick failure will occur.

(21) Mounting conditions of deformed bill.

A maximum of 10 identically deformed bills can be mounted at once.

To mount more than 10 bills at once will cause pitch failure or jamming.