

Connecting Mobile Device to Kiosk WiFi

Legacy, V5, and NanoMarket





Connecting a Mobile Device to Kiosk WiFi

Table of Contents

Purpose.....	1
Legacy MicroMarket – Connecting Mobile Device to Kiosk WiFi.....	1
V5 MicroMarket – Connecting Mobile Device to Kiosk WiFi.....	2
NanoMarket – Connecting Mobile Device to Kiosk WiFi.....	3
Manually Adding a Network	5


Connecting a Mobile Device to Kiosk WiFi

Purpose

The purpose of this document is to explain how to connect to the kiosk's WiFi on your mobile device.


Legacy MicroMarket – Connecting Mobile Device to Kiosk WiFi

1. Turn on your mobile device's WiFi.
2. Select the **VSH109069** network.




3. You will be prompted to enter the WiFi password and connect. *This password is only for internal use and should not be provided to consumers using kiosk.* The password is **399e6faece**.

4. Enter the password.



5. Select the **Connect** button and verify that you are now connected to the network.

Connecting a Mobile Device to Kiosk WiFi



V5 MicroMarket – Connecting Mobile Device to Kiosk WiFi

1. Turn on your mobile device's WiFi.
2. Select the **Operator WiFi** network.
Note: If you work for Five Star, select the network named **VSH109069**.




3. You will be prompted to enter the WiFi password and connect. *This password is only for internal use and should not be provided to consumers using the kiosk.* The password is **399e6faece**.


Connecting a Mobile Device to Kiosk WiFi



4. Enter the password.




5. Select the **Connect** button and verify that you are now connected to the network.




NanoMarket – Connecting Mobile Device to Kiosk WiFi

1. Turn on your mobile device's WiFi.
2. Select the **NanoMarket** network. This network ID is typically hidden so you may need to manually add it if you do not see it on the list. See the [Manually Add a Network](#) section for additional steps on how to do this.


Connecting a Mobile Device to Kiosk WiFi



3. You will be prompted to enter the WiFi password and connect. *This password is only for internal use and should not be provided to consumers using the kiosk.* The password is **Shinola7**.




4. Enter the password.
5. Select the **Connect** button and verify that you are now connected to the network.



Manually Adding a Network

1. If you do not see the WiFi name for the desired kiosk listed in the available networks, you will need to manually add the network. To do so, go into the WiFi settings on your mobile device.

2. Click the **Add Network** option.




3. Enter the network name. This will depend on the device you are connecting to:

- **Legacy** – VSH109069
- **V5** – Operator WiFi
- **FIVE STAR V5** – VSH109069
- **NanoMarket** – nanomarket

4. Select **WPA/WPA2-Personal** as the security type.

Connecting a Mobile Device to Kiosk WiFi

5. Enter the WiFi password. This will depend on the device you are connecting to:
 - **Legacy** – 399e6faece
 - **V5** – 399e6faece
 - **FIVE STAR V5** – 399e6faece
 - **NanoMarket** – Shinola7
6. Save the network and attempt to connect and verify the connection.



If you are still unable to connect to the WiFi, contact 365 Support at (888) 365- 6282.